

<b>Engine</b>	
Number .....	115
Oil .....	51, 65
Oil Filter .....	67
Overheats .....	89
Starting .....	34
Stop Switch .....	32, 34, 109
Stopping .....	109
<b>Environment</b> .....	114
<b>Equipment</b>	
Owner's Manual .....	38
Tool Kit .....	38
<b>F</b>	
<b>Flooded Engine</b> .....	34
<b>Front Seat</b> .....	63
<b>Fuel</b>	
Consumption Meter .....	20
Gauge .....	19
Mileage Meter .....	20
Oxygenated .....	122
Recommended .....	36
Remaining .....	19
<b>Tank Capacity</b> .....	36
<b>Fuses</b> .....	50, 105
<b>G</b>	
<b>Gasohol</b> .....	122
<b>Gasoline</b> .....	36
<b>H</b>	
<b>Hazard Switch</b> .....	32
<b>Headlight Aim</b> .....	85
<b>Headlight Assembly</b> .....	61
<b>Headlight Dimmer Switch</b> .....	32
<b>Helmet Holder</b> .....	37
<b>High Beam Indicator</b> .....	31
<b>High Coolant Temperature Indicator</b> .....	30, 89
<b>Honda Contacts</b> .....	126
<b>Horn Button</b> .....	32
<b>I</b>	
<b>Ignition Cut-off System</b>	
Banking Sensor .....	109
Side Stand .....	75