



## Storage Equipment *(Continued)*

### Luggage Tie-Down Hook

The luggage tie-down hooks are located on the underside of the rear seat.



Never use the tie-down hooks to tow or lift the motorcycle.

**Removing the Rear Seat** ➔ P.81