
Storage Equipment

The helmet holder and helmet set wire (in the tool kit) are located under the seat.



AWARNING

Riding with a helmet attached to the holder can interfere with the rear wheel or suspension and could cause a crash in which you can be seriously hurt or killed.

Use the helmet holder only while parked. Do not ride with a helmet secured by the holder.

▶ Use the helmet holder only when parked.

Removing the Seat <> P.59