

| | |
|---|------------|
| Removal | |
| Battery..... | 62 |
| Bulb Lid..... | 61 |
| Clip..... | 61 |
| Seat..... | 59 |
| Side Cover..... | 60 |
| Repair Kit..... | 92 |
| Reporting Safety Defects (U.S.)..... | 127 |
| Riding Precautions..... | 10 |
| | |
| S | |
| Safety Labels..... | 7 |
| Safety Precautions..... | 9 |
| Seat..... | 59 |
| Shifting Gears..... | 35 |
| Side Cover..... | 60 |
| Side Stand..... | 72 |
| Side Stand Ignition Cut-off System..... | 72 |
| Specifications..... | 128 |
| Speedometer..... | 19 |
| Start Button..... | 32, 34 |
| Starting the Engine..... | 34 |
| Steering Lock..... | 33 |

| | |
|-------------------------------------|------------|
| Stopping Engine..... | 108 |
| Storage | |
| Equipment..... | 37 |
| Owner's Manual..... | 38, 108 |
| Tool Kit..... | 38 |
| Storing Your Motorcycle..... | 112 |
| Switches..... | 32 |

T

| | |
|-----------------|----|
| Tachometer..... | 19 |
| Throttle..... | 80 |

Tires

| | |
|--|----------------|
| Air Pressure..... | 55 |
| Puncture..... | 92 |
| Replacing..... | 55, 92 |
| Transporting Your Motorcycle..... | 112 |
| Tripmeter..... | 20, 108 |
| Troubleshooting..... | 86 |
| Turn signal indicators..... | 31 |

V

| | |
|---|------------|
| Vehicle Identification Number..... | 114 |
|---|------------|