Gauges, Indicators & Displays

4		
1	control button A	Use this button for the following purposes:
		• To change indication of odometer, tripmeter A,
		and tripmeter B (pages 33, 35)
		 To change unit of speedometer, odometer,
		tripmeter and fuel mileage meter (page 40)
		To change indication mode of fuel mileage
		(page 42)
		To reset tripmeter A and fuel mileage meter
		(page 36)
		• To reset tripmeter B (page 36)
		To change the reset mode of tripmeter A and fuel
		mileage meter (page 39)
		• To adjust time (page 43)
		To change the setting of the shift indicator and
		selection of the display (pages $46 - 48$)
		To change unit of the temperature meter
		(page 41)
2	left turn signal indicator	Flashes when the left turn signal operates.
	(green)	Lamp Check.