
Gauges, Indicators & Displays

- 3. To set the hour, press control button A (3) until the desired hour is displayed.
 - The time is advanced by one hour each time the button is pressed.
 - Quick setting press and hold the button until the desired hour appears.



(3) control button A

4. Press control button B. The minute display will start blinking.

