

Low Fuel Indicator .....	27, 28
Low Oil Pressure Indicator .....	20, 87

**M**

<b>Maintenance</b>	
Fundamentals.....	42
Importance .....	37
Safety.....	38
Schedule .....	39
<b>Maximum Weight Limit.....</b>	<b>15</b>
<b>Modifications .....</b>	<b>14</b>

**N**

<b>Neutral Indicator .....</b>	<b>26</b>
--------------------------------	-----------

**O**

<b>Odometer .....</b>	<b>21, 107</b>
<b>Oil</b>	
Engine.....	48, 60
<b>Overheating .....</b>	<b>86</b>
<b>Oxygenated Fuels .....</b>	<b>121</b>

**P**

<b>Parking.....</b>	<b>13</b>
<b>Parts Location .....</b>	<b>16</b>
<b>PGM-FI (Programmed Fuel Injection)</b>	
malfunction indicator lamp (MIL)...	26, 87
<b>Protective Apparel.....</b>	<b>9</b>

**R**

<b>Rear Seat.....</b>	<b>56</b>
<b>Rear Suspension .....</b>	<b>81</b>
<b>Recommended</b>	
Coolant.....	50
Fuel.....	34
Oil.....	48
<b>Refueling .....</b>	<b>34</b>
<b>Removal</b>	
Front Seat .....	55
Lower Fairing.....	57
Rear Seat.....	56
<b>Repair Kit.....</b>	<b>89</b>
<b>Reporting Safety Defects (U.S.).....</b>	<b>128</b>
<b>REV (Tachometer Red Zone)</b>	
indicator.....	27, 29