The average fuel mileage and fuel consumption will be based on tripmeter A.

- Current fuel mileage: Current instant fuel mileage. If your speed is 0.6 mph (1 km/h) or less, "---" is displayed.
- Average fuel mileage:
 Average fuel mileage since tripmeter A was reset. When "--" is displayed, see your dealer for service.
- Fuel consumption:
 Total fuel consumption since tripmeter A was reset. When "---" is displayed, see your dealer for service.
 - ► To reset the average fuel mileage and fuel consumption: →P.22