


## ■ Rear Turn Signal Bulb


1. Remove the screw.
2. Remove the turn signal lens and lens packing.
3. Slightly press the bulb and turn it counterclockwise.



4. Install a new bulb in the reverse order of removal.  
► Use only the amber bulb.

## ■ License Plate Light Bulb

1. Remove the screws.
2. Remove the license light cover and license light cover packing.
3. Pull the bulb out of the socket without turning it.



4. Install a new bulb in the reverse order of removal.
5. Reinstall the cover