

## Instruments (Continued)


### Circuit mode

#### To Change to the circuit mode :

- Press and hold the **LAP** button with your motorcycle stopped.
  - u To return to the street mode display, press and hold the **LAP** button.
- Select the "CIRCUIT" menu on the "DISPLAY" screen. **➡P.43** **➡P.59**
  - u To return to the street mode display, select the "STREET" menu on the "DISPLAY"

#### Lap timer

**➡P.86**



#### LAP button



### Display Check

When the ignition switch is turned to the ON position, the opening symbol will show on the display. If the display itself does not shows when it should, have your dealer check for problems.