

Instruments *(Continued)*

DISPLAY

To Set the DISPLAY Menu

- 1 Select the "DISPLAY" menu on the main menu screen. **➡P.43**
- 2 Select the menu by pressing the **SEL ▲** (up) or **SEL ▼** (down) button and press the **MODE** button.

To End the Setting

Select the **◀** (return) on the menu screen. The display returns to the "DISPLAY" menu on the main menu screen.

➡ Press the **MODE** button

➡ Press the **SEL ▲** (up) button

➡ Press the **SEL ▼** (down) button

"DISPLAY" is selected

