## To Shift to the Setting Mode

Press and hold the MODE button and SEL (up) or SEL (down) button until main menu screen is displayed with your motorcycle stopped.

## Main menu screen



Select a menu by pressing the SEL (up) or SEL (down) button and press the MODE button.

▶ Press and hold the SEL ▲ (up) or SEL ▼ (down) button to move the menu quickly.