

## Setting the riding mode

### CBR1000RR/RA

You can change the P, T, W and EB values on the USER 1 and USER 2 of the riding mode.

### CBR1000S1

You can change the P, T, W, EB value and S mode on the USER 1 and USER 2 of the riding mode.

- 1 Stop the motorcycle.
- 2 Select the USER 1 or USER 2 in the riding mode you want to set. ➔ P.104
- 3 Press and hold the **MODE** button until P value is selected.
- 4 Press the **SEL** ▲ (up) or **SEL** ▼ (down) button until the desired value is displayed.
- 5 Press the **MODE** button until T value is selected.
- 6 Press the **SEL** ▲ (up) or **SEL** ▼ (down) button until the desired value is displayed.
  - ▶ T value can be changed to level 0 by pressing and holding the **SEL** ▼ (down) button at the time of level 1.
- 7 Press the **MODE** button until W value is selected.
- 8 Press the **SEL** ▲ (up) or **SEL** ▼ (down) button until the desired value is displayed.
- 9 Press the **MODE** button until EB value is selected.
- 10 Press the **SEL** ▲ (up) or **SEL** ▼ (down) button until the desired value is displayed.