

Riding mode *(Continued)*

11 CBR1000S1

Press the **MODE** button until S mode is selected.

12 CBR1000S1

Press the **SEL** **▲** (up) or **SEL** **▼** (down) button until the desired mode is displayed.

13 Press and hold the **MODE** button until ordinary display is displayed.

You can stop setting the riding modes at any time by pressing and holding the **MODE** button.