

Troubleshooting

Engine Will Not Start	P. 76	Other Warning Indications	P. 79
Overheating (Segment H flashes in coolant temperature gauge)	P. 77	Fuel Gauge Failure Indication.....	P. 79
Warning Indicators on or Flashing	P. 78	Coolant temperature Gauge Failure Indication	P. 79
PGM-FI (Programmed Fuel Injection)		Tire Puncture	P. 80
Malfunction Indicator Lamp (MIL).....	P. 78	Electrical Trouble	P. 86
ABS (Anti-lock Brake System) Indicator (CBR250RA only).....	P. 78	Battery Goes Dead	P. 86
		Burned-out Light Bulb	P. 86
		Blown Fuse.....	P. 90