

Engine

Number.....	114
Oil.....	44, 63
Oil Filter.....	65
Overheats.....	87
Starting.....	27
Stop Switch.....	24, 27, 106
Stopping.....	106
Will Not Start.....	86

Environment	113
--------------------------	-----

Equipment

Owner's Manual.....	30, 106
Tool Kit.....	30

F

Flooded Engine	27
-----------------------------	----

Front Seat	55
-------------------------	----

Front/Rear Turn Signal	99
-------------------------------------	----

Fuel

Gauge.....	19
Recommended.....	29
Remaining.....	19
Tank Capacity.....	29

Fuses	43, 101
--------------------	---------

G

Gasohol	121
----------------------	-----

Gasoline	29
-----------------------	----

H

Harness Band Clip	56
--------------------------------	----

Headlight	98
------------------------	----

Headlight Aim	83
----------------------------	----

Headlight Dimmer Switch	24
--------------------------------------	----

Helmet Holder	30
----------------------------	----

High Beam Indicator	23
----------------------------------	----

Honda Contacts	124
-----------------------------	-----

Horn Button	24
--------------------------	----

I**Ignition Cut-off System**

Banking Sensor.....	106
---------------------	-----

Side Stand.....	73
-----------------	----

Ignition Key	105
---------------------------	-----

Ignition Switch	25, 27, 106
------------------------------	-------------

Indicators	22
-------------------------	----

Information Record	130
---------------------------------	-----

Instruments	18
--------------------------	----