
Removing & Installing Body Components ► Front Seat



Front Seat

Removal

- **1.** Pull the rear corners of the front seat up, then remove the mounting bolts.
- 2. Pull the front seat back and up.

Installation

- 1. Insert the tab into the recess.
- 2. Install and tighten the mounting bolts securely.

Make sure that the seat is locked securely in position to pull it up lightly.