

N		
Neutral Indicator	31	
O		
Odometer	20, 109	
Oil		
Engine	52, 65	
Other Warning Indications	94	
Overheating	91	
Oxygenated Fuels	123	
P		
Parking	12	
Parts Location	16	
PGM-FI (Programmed Fuel Injection)		
Malfunction Indicator Lamp (MIL)	31, 92	
Protective Apparel	9	
R		
Rear Seat	63	
Rear Suspension	88	
Recommended		
Coolant	55	
Fuel	37	
Oil	52	
Refueling	37	
Removal		
Battery	60	
Clip	61	
Front Seat	62	
Rear Seat	63	
Right Side Cover	64	
Repair Kit	95	
Reporting Safety Defects (U.S.)	128	
Riding Precautions	10	
Right Side Cover	64	
S		
Safety Labels	7	
Safety Precautions	9	
Shifting Gears	36	
Side Stand	75	
Side Stand Ignition Cut-off System	75	
Specifications	129	
Speedometer	19	
Start Button	32, 35	
Starting the Engine	35	
Steering Lock	34	