

Removal

1. Remove the bolts A, bolt B, bolt C, bolt D, collar and clips. 2 P. 50
2. Remove the right lower fairing.

Installation

Install the parts in the reverse order of removal.