

- 3 Press the **MODE** button. The second digit starts flashing.



- 4 Repeat the steps 2 and 3 for setting of the second and first digits.
- 5 Press the **MODE** button. The trip distance is set, and then the display will return to the ordinary display.

The trip distance will not be reset when you complete setting of the subtraction trip by pressing the **MODE** button only or when you set the trip distance to the same as the current distance. When entering the setting mode using "km" unit after setting the trip distance to 621 mile" or more with the unit set to "mile", "999.1" or more will appear. Press the **SEL** **▲** (up) button or the **SEL** **▼** (down) button to display "000.0", and then set the trip distance again if necessary.