

Instruments *(Continued)*

7 Setting the subtraction trip:

- 1 The preset figure is displayed and the third digit will be flashing.



- 2 To set the third digit, press the **SEL** (up) button or the **SEL** (down) button until the desired figure appears.
 - ▶ Press and hold the **SEL** (up) button or the **SEL** (down) button to advance the figure fast.



→ Press the **SEL** (up) button

→ Press the **SEL** (down) button