

Display

Following items can be changed sequentially.

- Display Mode (this page)
- Brightness **▶P.79**
- Background **▶P.80**
- Favorite Information **▶P.82**
- Favorite Switch **▶P.84**

Display Mode

You can select the riding information image.

