# **Starting & Stopping the Engine**

### **Flooded Engine**

If the engine fails to start after repeated attempts, it may be flooded with excess fuel. To clear a flooded engine:

#### Using The Start Button

- 1. Push the choke knob in all the way to OFF.
- 2. Open the throttle fully.
- 3. Press the start button for 5 seconds.
- 4. Follow the *High Air Temperature* starting procedure (page 34).

#### Using The Kickstarter

- 1. Turn the engine stop switch to OFF  $(\boxtimes)$ .
- 2. Push the choke knob in all the way to OFF.
- 3. Open the throttle fully.
- 4. Crank the engine several times with the kickstarter.
- 5. Turn the engine stop switch to RUN ( $\bigcirc$ ).
- 6. Follow the *High Air Temperature* starting procedure (page 34).

## **How to Stop the Engine**

To stop the engine, shift into neutral, turn the engine stop switch to OFF (x).