Frequency Items		Whichever Comes First		Initial Maint.	Regular Maint. Interval				
		⇒	mi	100	600	1,200	1,800	2,400	Refer to page:
			km	150	1,000	2,000	3,000	4,000	
		Note	Month	1	6	12	18	24	
*	Fuel Line					Ι		Ι	-
*	Throttle Operation					Ι		Ι	73
	Air Cleaner	Note 1			С	С	С	С	69
	Crankcase Breather				Ι	Ι	Ι	Ι	72
	Spark Plug				Ι	Ι	Ι	Ι	82
*	Valve Clearance			Ι	Ι	Ι	Ι	Ι	78
	Engine Oil			R	R	R	R	R	63
* *	Engine Oil Strainer Screen					С		С	-
* *	Engine Oil Centrifugal Filter					С		С	-
* *	Engine Idle Speed			Ι	Ι	Ι	Ι	Ι	81

* Should be serviced by your dealer, unless the owner has the proper tools and service data and is mechanically qualified. Refer to the official Honda Service Manual (page 160).
** In the interest of safety, we recommend these items be serviced only by your dealer.