## Is Your Motorcycle Ready to Ride?

Leaks Look under the motorcycle for

signs of leaking fluids (fuel, engine oil, brake fluid).

Engine Oil Check the level and add oil if

needed (page 64).

Fuel Check the level and add fuel

(page 59) if needed. Also make sure the fuel fill cap is securely

fastened.

Drive Chain Check the condition and slack.

Adjust and lubricate if needed. Also check the chain slider for wear and replace if needed

(page 104).

Cables Check the cable housings for

wear. Check the fittings for looseness. Replace or tighten as

needed.

Nuts & Bolts Use a wrench to make sure all

accessible nuts, bolts, and

fasteners are tight.

Spark Plug Check for looseness (page 78).

& Cap