


## Fuel Valve

LEFT SIDE



The three-way fuel valve is used to control the flow of fuel from the fuel tank to the carburetor.

**ON**

Turning the fuel valve ON before attempting to start the engine allows fuel to flow from the fuel tank to the carburetor.

**OFF**

Turning the fuel valve OFF after stopping the engine prevents the flow of fuel from the fuel tank to the carburetor.

**RES**

Turning the fuel valve to RES allows fuel to flow from the reserve fuel supply to the carburetor.