


## Brake Pad Wear

Brake pad wear depends on the severity of usage, the type of riding, and riding area conditions. (Generally, the pads will wear faster on wet and dirty riding terrain.) Inspect the pads at each regular maintenance interval (page 48).

LEFT FRONT



Check the cutout (2) in each pad. If either pad is worn to the cutout, replace both pads as a set. See your dealer for this service.

## Other Inspections

Check that the front lever assembly is positioned properly and the securing bolts are tight.

## More About: Brake Fluid

Brake fluid should be added and replaced by your dealer.

The recommended brake fluid is Honda DOT 4 Brake Fluid, or any brake fluid of equal quality and performance. Use fresh brake fluid from a sealed container.