Quick Reference

These symbols are used in Operating Controls section:

SYMBOL	COMPONENT	SEE PAGE
•	ON – ignition switch	15
OFF	OFF – ignition switch	15
(3)	START button	16
	fuel reserve indicator	18