

Index

A

- accessories 3
- adjustments,
 - chassis..... 139
 - control freeplay 59, 62
 - for competition 125
 - gearing..... 140
 - personal fit..... 142
 - suspension, front..... 127
 - suspension, rear 130
 - suspension, track conditions..... 134
 - tire selection, track condition 141
- after competition maintenance 31
- air cleaner 56
- air pressure,
 - front suspension..... 127
 - tires 110
- apparel, protective 2
- appearance care 123
- authorized manuals 166

B

- basic operation..... 15
- battery 121
- before riding 11
- between motos & practice maintenance 30
- brakes,
 - fluid level..... 106
 - lever, front adjustment..... 105
 - pad wear 108
 - pedal height 105
- break-in guidelines 19

C

- capacity, fuel 41
- care, appearance 123
- chain, drive..... 112
- chassis adjustments 139
- cleaner, air 56
- cleaning, appearance care 123
- clutch system, adjustment 62
- competition logbook 160
- consumer information 165
- contacting Honda 167
- controls..... 5
- coolant..... 54
- customer service..... 165
- cylinder system 81

D

- damping adjustments,
 - front..... 127
 - rear 131
- dealer, your Honda..... 168
- diagram, wiring 164
- drive chain..... 112

E

- engine,
 - does not start..... 147
 - idle speed 61
 - lacks power..... 147
 - mode select button..... 126
 - number..... 154
 - oil..... 51
 - pinging..... 41
 - starting 17
 - stop button 18
 - stopping 18
- environment, protecting..... 146

F

- filter,
 - air 56
 - fuel pump..... 45
 - oil..... 52
- fork,
 - front suspension adjustments..... 127
 - front suspension inspection 88
 - oil recommendation 91
- front brake lever adjustment 105
- front suspension maintenance..... 127
- fuel 41
- fuel,
 - line inspection..... 41
 - line replacement 42
 - oxygenated..... 159
 - pump filter 45
 - refueling..... 41
 - system..... 41
 - tank capacity..... 41