


Storage Equipment

Helmet holders



Seat Open

Insert the ignition key into the seat lock and turn it clockwise to unlock.

Seat Close

Close and push down on the rear of the seat until it locks. Make sure that the seat is locked securely to pull it up lightly.

Helmet Holders

The helmet holders are located under the seat.

- Use the helmet holders only when parked.

⚠ WARNING

Riding with a helmet attached to the holder can interfere with your ability to safely operate the vehicle and could lead to a crash in which you can be seriously hurt or killed.

Use the helmet holder only while parked. Do not ride with a helmet secured by the holder.