


Fuel Valve

The three-way fuel valve is used to control the flow of fuel from the fuel tank to the carburetor.



- U (ON): normal position for riding.
- (OFF): for parking, storing, or transportation.
- U (RES): for extra fuel to get to a gas station for refuelling.