


Inspecting the Front Brake Lever Freeplay

1. Place your motorcycle on its centre stand on a firm, level surface.
2. Measure the distance the front brake lever moves before the brake takes hold.

Freeplay at the tip of the brake lever:
10 to 20 mm (0.4 to 0.8 in)



Check the brake cable for kinks or signs of wear. If necessary have it replaced by your dealer.

Lubricate the brake cable with a commercially available cable lubricant to prevent premature wear and corrosion.

Make sure the brake arm, spring and fastener are in good condition.