iPod®/USB Flash Drive

Playing an iPod®

Connect the iPod[®] using your dock connector to the USB cable (see page 103), then push the AUX button twice and iPod[®] indicator will be displayed. If you see an error message in the display, see page 112.

12:30 AAAAAAAA 8888888999999 11 10" 000212367 mi TRIPA 321.4 mi