Engine Oil & Filter

Add Engine Oil:

- 11. Fill the crankcase with the recommended oil (page 144), approximately: 3.9 US qt (3.7 ℓ)
- 12. Install the oil fill cap/dipstick securely.
- 13. Start the engine and let it idle for 3-5 minutes.
- 14. Stop the engine and wait 2 3 minutes.
- 15. Check that the oil level is at upper level mark on the dipstick (page 146).
- 16. Check that there are no oil leaks.

If a torque wrench is not used for installation, see your dealer as soon as possible to verify proper assembly.