iPod®/USB Flash Drive

This audio system can play the audio files on the iPod[®] and a USB flash drive. To play an iPod[®] or a USB flash drive, connect it to the USB cable in the left saddlebag (page 103).

 $iPod\ touch^{\otimes}$, $iPod^{\otimes}$, $iPod\ nano^{\otimes}$ are registered trademarks of Apple Inc. in the U.S. and other countries.

Use any USB flash drive and iPod[®] at your own risk. In no event shall Honda be liable for any damages or troubles in use.

Playable iPod® /USB Flash Drive

Compatible Devices

iPods[®] and USB flash drives compatible with your audio system are:

Device	Support Requirements
USB flash drive	265 M bytes or more
Hard disk drive	Not support
Card reader/Memory reader	Not support
CD/DVD/FD drive	Not support
USB hub	Not support
iPod nano [®] 1st generation	F/W Ver. 1.2.0 or later
iPod nano [®] 2nd generation	F/W Ver. 1.1.2 or later
iPod nano [®] 3rd generation	F/W Ver. 1.0.0 or later
iPod nano [®] 4th generation	F/W Ver. 1.0.0 or later
iPod nano [®] 5th generation	F/W Ver. 1.0.0 or later
iPod nano [®] 6th generation	F/W Ver. 1.0.0 or later
iPod touch® 1st generation	F/W Ver. 1.2.0 or later
iPod touch® 2nd generation	F/W Ver. 1.0.0 or later
iPod touch® 3rd generation	F/W Ver. 4.2.0 or later