Color Label & Code

The color label is attached inside the fuel fill compartment lid.

The color code is helpful when ordering replacement parts. You may record the color and code in the Quick Reference section at the rear of this manual.

