


Instruments (Continued)

INFO 1 Display

Odometer & Tripmeter display

Cruise control set speed &
Air temperature gauge display



Fuel gauge

GL1800/D/DA Available driving distance
& Tire pressure gauge display

GL1800B/BD Available driving distance
display


INFO 1 display contains the following:

- Cruise control set speed () and Air temperature gauge [AIR] display ➔ P.35
- Odometer [TOTAL] & Tripmeter [TRIP A/ TRIP B] display ➔ P.36

- **GL1800/D/DA** Available driving distance [RANGE] & Tire pressure gauge [() FR/RR] display ➔ P.37
- **GL1800B/BD** Available driving distance [RANGE] display ➔ P.37
- Fuel gauge ➔ P.38

Changing the INFO 1 Display

Press **SEL** button to move the cursor to a desired display.



GL1800/D/DA

Odometer & Tripmeter display

Cruise control set speed &
Air temperature gauge display



Available driving distance &
Tire pressure gauge display

➔ Press **SEL** button.