


Windscreen Ventilation Louver

You can utilize the windscreen ventilation louver to direct the flow of fresh air.

To Operate the Windscreen Ventilation Louver

Press the release button, then the windscreen ventilation louver pops-up.



To Close the Windscreen Ventilation Louver

Push the center of the louver until the louver is firmly closed.