

After removing your motorcycle from storage, inspect all maintenance items required by the Maintenance Schedule.

USA For more information about storage, refer to the *Honda Winter Storage Guide*, available from your dealer.

Canada For more information about storage, visit our website at www.honda.ca and look up “Storage Tips” under the “Honda Warranty” in the Warranty tab for your Model.

Transporting Your Motorcycle

If your motorcycle needs to be transported, it should be carried on a motorcycle trailer or a flatbed truck or trailer that has a loading ramp or lifting platform, and motorcycle tie-down straps. Never try to tow your motorcycle with a wheel or wheels on the ground.

NOTICE

- Towing your motorcycle can cause serious damage to the transmission.
- When tying down the motorcycle for transportation, do not use tie-downs or straps on the handlebars or handgrips. Doing so may cause damage to the steering system, heated grips and/or handlebar switches.

Tie-down Method

1. Remove both sides of the cylinder head side covers. ➤ P. 154
2. Secure the motorcycle using a buckle or ratchet style tie-down strap to the engine guards and affix the other ends to an anchor point.
 - ▶ Make sure the tie-downs straps are tight and the motorcycle is secure.

