

D	
D (AT MODE) Indicator	39
Digital Clock Adjustment	78
E	
Elapsed Time	26
Electrical Adjustable	
Suspension	29, 172
Electrical Trouble	207
Emergency Key	212
Emission Control Systems	227
Engine	
Number	225
Oil	148, 158
Oil Filter	159
Overheats	178
Starting	112
Stop Switch	52, 112, 214
Will Not Start	177
Environment	224
Equipment	
Fairing Pocket	129
Helmet Holder	131
Helmet Holder Hanger	131
Saddlebags	128
Shelter Case	131
Tool Kit	132
Travel Trunk	128

F	
Fairing Pocket	129
Final Drive Oil	149, 163
Flooded Engine	113
FM Radio	92
4-way Key/ENT Switch	50, 51
Front Brake Lever Adjustment	171
Front Suspension	172
Fuel	
Average Fuel Mileage	26
Current Fuel Mileage	26
Gauge	38, 183
Low Fuel Indicator	44
Recommended	127
Remaining	38
Tank Capacity	127
Fuses	148, 209
G	
Gasohol	231
Gasoline	127
Gear Position Indicator	39
Gear Shift Operation	116
H	
Handle Grip Heater	133
Handle Grip Heater Button	48
Handle Grip Heater Indicator	42, 183
Hazard Switch	52
Headlight Aim	171
Headlight Dimmer Switch	50, 51

Helmet Holder	131
High Beam Indicator	45
High Coolant Temperature	
Indicator	47, 178
Hill Start Assist	126
Hill Start Assist (HSA)	
Indicator	46, 126, 182
Home Button	48
Home Switch	50, 51
Honda Contacts	234
Honda Selectable Torque Control	
(Torque Control)	122
Honda SMART Key	
Answer Back Button	54
Battery	174
LED	54
ON/OFF button	54
UNLOCK Button	54
Honda SMART Key Battery	174
Honda SMART Key Does Not	
Operate Properly	188
Honda SMART Key Indicator	45, 180
Honda SMART Key System	56, 216
Horn Button	50, 51
HSTC (Honda Selectable Torque	
Control)	31