

## Controls Locations

(Models not equipped with Navigation System)

LEFT HANDLEBAR

TALK lever  
(for accessory CB radio)

CB radio levers  
(for accessory CB radio)

VOLUME lever

TUNE/CH lever

MUTE button

CB button (for accessory CB radio)

TITLE button

AUDIO button

I-COM button

AM button

FM button

A.SEL  
RPT/RDM button

VOLUME  
knob/button

WB button

MODE  
knob/button

AUX button

RETURN button

preset buttons

The CB lever and button function when the Honda accessory CB radio is installed. For CB operating instructions, refer to the accessory manual.