Multi Information Display

On/Off-Opening/Ending Ceremony

(Models not equipped with Navigation System)

The opening/ending ceremony can be turned off.

- 1. Push the SETUP button to show the CLOCK ADJUST display (page 30).
- Push the DIM button to show the OPENING/ENDING CEREMONY display.
- 3. Push the TRIP or INFO button to switch ON/OFF.
- 4. Push the SETUP button to fix the setting.

When approximately 5 seconds pass without operating a button on the OPENING/ENDING CEREMONY display, the display automatically returns to the previous display.

ceremony display ON



ceremony display OFF

