



Navigation System

System Control

To turn the Navi voice on with the Navigation System turned off – push the NAVI button.

To turn the Navi voice off with the Navigation System turned on – push and hold the NAVI button.



Switch Output

When the navigation voice guidance is turned on, you can switch its output between Speaker and Headset (optional equipment).

- Push the NAVI button switches output.

