

# Navigation System

## Navi Volume Control


To select the volume control, push the VOLUME knob/button until “NAVI VOL” is displayed (page 98). Then, within the 5 seconds, change the navigation volume control.

To make the Navi volume louder than the audio volume – push the VOLUME lever up or turn the VOLUME knob/button clockwise.

To make the Navi volume quieter than the audio volume – push the VOLUME lever down or turn the VOLUME knob/button counterclockwise.

To increase or decrease the volume rapidly – push the VOLUME lever up or down and hold it down.

(NAVI VOLUME level ranges: from 5 down to -5)



## NAVI Volume

