

# Riding with Cruise Control

---

## To Manually Increase the Set Speed

1. Use the throttle to accelerate until you reach the desired speed.
2. Push and release the SET/DECEL switch.

## To Manually Increase Vehicle Speed

1. Use the throttle in the normal manner to accelerate.
2. To return to the set speed, close the throttle and coast without applying the brakes. The cruise system will maintain the speed you previously set.

## **To Cancel Cruise Control**

### To Disengage the System

1. Push the CRUISE CONTROL master switch until the CRUISE ON indicator goes off. (The set speed will be erased from memory.)

### To Temporarily Disengage the System

1. Pull the brake lever or clutch lever slightly, or step on the brake pedal slightly, or close the throttle. (The set speed will remain in memory.)
2. To resume cruise control:
  - If you are still over 30 mph (48 km/h) – push the RESUME/ACCEL switch.
  - If you are under 30 mph (48 km/h) – use the throttle to increase road speed above 30 mph (48 km/h) and then push the RESUME/ACCEL switch.