


Muting

To mute the audio and navi volume – push the MUTE button.

The display will indicate “MUTE”.


To restore the original volume – push the MUTE button again to restore the original volume.

LEFT HANDLEBAR



(Models not equipped with Navigation System)

MUTE indicator



(Models equipped with Navigation System)

MUTE indicator

