

# Instruments

Multi-information display  P. 23

## Speedometer

Shows riding speed in miles per hour (mph) and kilometer per hour (km/h).


## Tachometer

### NOTICE

Do not operate the engine in the tachometer red zone. Excessive engine speed can adversely affect engine life.


## Tachometer red zone

(excessive engine rpm range)



INFO 1 display  P. 34

INFO 2 display  P. 39

INFO 3 display  P. 41

## Display Check

When the ignition switch is turned ON, all of the modes and digital segments will show on the INFO 1, INFO 2 and INFO 3 displays, and the opening symbol will show on the multi-information display.

If the displays do not show when they should, have your dealer check for problems.