


## Instruments (Continued)

### INFO 1 Display

#### Odometer & Tripmeter display

Cruise control set speed &  
Air temperature gauge display



Fuel gauge

**GL1800/D/DA** Available driving distance  
& Tire pressure gauge display

**GL1800B/BD** Available driving distance  
display


INFO 1 display contains the following:

- Cruise control set speed ( ) and Air temperature gauge [AIR] display ➔ P.35
- Odometer [TOTAL] & Tripmeter [TRIP A/ TRIP B] display ➔ P.36

- **GL1800/D/DA** Available driving distance [RANGE] & Tire pressure gauge [ ( ) FR/RR] display ➔ P.37
- **GL1800B/BD** Available driving distance [RANGE] display ➔ P.37
- Fuel gauge ➔ P.38

### Changing the INFO 1 Display

Press **SEL** button to move the cursor to a desired display.



**GL1800/D/DA**

#### Odometer & Tripmeter display

Cruise control set speed &  
Air temperature gauge display



Available driving distance &  
Tire pressure gauge display

➔ Press **SEL** button.