



## Audio System (Continued)

### To Connect Your iPhone/iPod/USB Device

GL1800DA iPhone/iPod/USB device



Except GL1800DA Certified cable for the device to be connected



- 1 **GL1800DA**  
Open the travel trunk. ➔ P. 128

Except GL1800DA


- 2 Open the shelter case. ➔ P. 131

- 2 Connect your iPhone/iPod/USB device using a certified cable to the USB connector or connect a USB flash drive, etc. to the USB connector directly. After connecting, the UBS icon appears on the screen.

### To Disconnect Your iPhone/iPod/USB Device

You can disconnect your iPhone/iPod/USB device at any time. Make sure to follow the device's instructions on how to disconnect the device from the cable.

When you disconnect your device, the USB icon will disappear from the screen.



- 3 Store your device in the travel trunk (GL1800DA) or shelter case (Except GL1800DA).
- 4 Close the travel trunk or shelter case.