



➡ : Press the **MODE** button

GL1800/B

Press one of the **MODE** buttons (▲ or ▼) while the throttle is fully closed.

- ▶ The riding mode indicator blinks until the riding mode is changed.
- ▶ The riding mode does not change until the throttle is fully closed.
- ▶ Each time the ignition switch is turned to ON, the riding mode will automatically be set to **TOUR** mode.



➡ : Press the **MODE** (▲) button

➡ : Press the **MODE** (▼) button

If all the segments of the riding mode indicator are displayed, see your dealer for servicing.